

Upgrade by USB (chap 12 of user manual)

This function is only valid when the USB device has been plugged-in and attached at the receiver box.

there are two methods to update firmware, as following:

Select to update the firmware from via a USB stick

- 1) Copy the new firmware to the root directory of a USB stick, and connect it to the USB HOST port of the player then press ENTER to confirm
- 2) Input password "666666" on main menu, system can update firmware automatically
- 3) Please restart N150H after software upgrade complete